



Alarm.com Slim Line Doorbell Camera - Quick Start Guide

Last updated: Jan 25, 2018



+ Table of contents

Visit alarm.com/doorbell for installation instructions.

Push Notifications

Use the Alarm.com app to set up instant alerts:



Button Pushed

Be notified when the doorbell button is pushed.



Motion

Be notified when the Doorbell Camera detects motion.

Tap on a doorbell notification to open the call screen so you can see and speak with your visitors.

Quick Tip: To respond to doorbell notifications even faster, check "Keep me logged in" on the Alarm.com app login screen.

Video Recording Rules

Use the Alarm.com app to choose which events trigger your Doorbell Camera video clip recordings:



Button Pushed

Record when the doorbell button is pushed.



Motion

Record when the Doorbell Camera detects motion.



Event Triggered

Record when a sensor in your Alarm.com system is activated or an alarm is triggered.

Quick Tip: You can view recorded clips on the Alarm.com app and Customer Website.

LED Reference Guide**Normal Operation****Green | Solid**

Ready and working normally
Use the Alarm.com app or Customer Website to choose a custom color in place of default green.

White | Solid

In Call mode
A call has been initiated or is occurring.

Requires Attention**Orange | Rapid double flash**

No Wi-Fi connectivity
Check your Internet connection.

Blue | Rapid double flash

Power supply issue
Contact your installer.

Troubleshooting**Red | Green | Alternating flash**

Push & hold ~60 sec until flashing

Wi-Fi Access Point Mode
Connect to the camera's temporary network and use the app to update Wi-Fi settings.

Blue | Flashing

Push & hold ~70 sec until flashing

Power cycle
Reboots the camera.

Yellow | Flashing



Push & hold ~80 sec until flashing

Factory Reset
Use to factory reset the camera.
Deletes all Wi-Fi and configuration information.

Additional resources

[Academy](#) Enroll in the [Alarm.com Doorbell Camera 201](#) training course today! For more information on accessing Academy Training, see [How can I access the Training Center on the Dealer Website?](#).

Contact your installer or visit www.alarm.com/doorbell for helpful videos and a full LED Reference Guide.

If you are a professional installer, visit www.alarm.com/supportcenter.

[Skybell Trim Plus](#)

[Back to top ▲](#)

[◀ Alarm.com Slim Line D...](#) | [Alarm.com Wi-Fi Door...](#) ▶

Was this article helpful?

Yes No

Recommended articles

- [Alarm.com Wi-Fi Doorbell Camera - Quick Start Guide](#)
- [Alarm.com Wi-Fi Doorbell Camera and Slim Line - Installation Guide](#)
- [Alarm.com Wi-Fi Doorbell Camera Hardware Installation Video](#)
- [Alarm.com Slim Line Doorbell Camera - LED and Troubleshooting Reference Guide](#)

Article type:
Installation

Tags:
[ADC-VDB101](#), [ADC-VDB105](#), [add](#), [bell](#), [camera](#), [cameras](#), [connect](#), [device](#), [door](#), [guide](#), [install](#), [installation](#), [installing](#), [setup](#), [skybell](#), [Skybell Trim Plus](#), [slim](#), [steps](#), [sync](#), [Vdb105](#), [video](#), [wire](#)