



# Knowledge Base

powered by  **ALARM.COM**







---

## What do the LEDs on the ADC-V522IR mean?




[https://answers.alarm.com/ADC/Partner/Installation\\_and\\_Troubleshooting/Video\\_Devices/Indoor\\_Fixed\\_IR\\_ADC-V522IR/Wh...](https://answers.alarm.com/ADC/Partner/Installation_and_Troubleshooting/Video_Devices/Indoor_Fixed_IR_ADC-V522IR/Wh...)

Updated: Thu, 21 Oct 2021 06:24:17 GMT

LED pattern	Status	Description
<b>Green   Solid</b> 	Connected to the internet	Local network and internet connection with Alarm.com IP.
<b>Green   Flashing</b> 	Local network connection	Local network connection with local IP address, no internet.  <b>Note:</b> If the LED does not go solid green after a few minutes, see <a href="#">Camera LED is blinking green</a> .
<b>Red   Solid</b> 	Power on, or no network connection	Power on, system booting up typically 60-90 seconds.  If solid red for longer than 60-90 seconds, then there is no local or Internet connection.
<b>Red   Flashing</b> 	Camera powering on, or firmware update	Camera is powering on, or a firmware update is in progress.
<b>Blue   Flashing</b> 	WPS mode	WPS mode is active. To enter WPS mode, press and hold the WPS button for about 3 seconds.
<b>White   Flashing</b> 	AP mode	Wi-Fi access point (AP) mode is active. To enter AP mode, press and hold the WPS button for about 6 seconds.



<p>Red &amp; Green   Flashing</p> 	<p>Factory reset</p>	<p>The camera is restoring to factory default settings.</p> <p><b>Caution:</b> If the camera is already installed, it may need to be removed from the Alarm.com account and re-added after a factory reset.</p> <p>To perform a factory reset, press and hold the reset button for about 10-15 seconds.</p>
---	----------------------	---

**Note:** The WPS and reset options share the same button on the ADC-522IR.

